

Set-up




Volume




The vario is silent on the ground.
Changing the volume will activate it. default parameter

Vario settings




default parameter

Installation




Shoulder strap or cockpit installation recommended

Weak lift buzzer (during flight)




default parameter

Advanced settings




default parameter

ON / OFF




USB-C earphones output



USB-C to Jack 3.5mm adapter available at stodeus.com

Battery charge



Do not place the device behind a window or the windshield of a car as it will damage the battery.

Factory reset



Default parameters:
Up sensitivity: **+10cm/s**
Integration time: **50%**
Sink alarm: **OFF**
Take-off detection: **ON**
Weak lift buzzer: **OFF**
Volume: **medium**
Auto power off: **30min**